



OPERATING MANUAL

VAN VEEN LOOP ANTENNA

VVL 1530

REVISION LEVEL 1.1
© AFJ Instruments 2014

GENERAL INFORMATION

The information contained herein, are provided in connection with the usage of AFJ VVL 1530 Van Veen Loop Antenna only.

All information contained herein, is subject to change without prior notice and cannot be duplicated, copied or reproduced in whole or part, without prior written consent of the owner:

AFJ Instruments, Via F.lli Lorenzetti 6, 20146 – Milan, Italy

Phone: +39 02 91434850

E-mail: sales@afj-instruments.com

Website: www.afj-instruments.com

All efforts have been made to ensure the accuracy of the contents of this document. However, the supplier can assume no liability whatsoever for any errors in this manual or their consequences, direct and/or indirect.

STATEMENT OF COMPLIANCE

The AFJ VVL 1530 antennas are designed and built in accordance with CISPR 15: Limits and methods of measurement of radio disturbance characteristics of electrical lighting and similar equipment

Applies to the emission (radiated and conducted) of radio frequency disturbances from: all lighting equipment with a primary function of generating and/or distributing light intended for illumination purposes, and intended either for connection to the low voltage electricity supply or for battery operation; the lighting part of multi-function equipment where one of the primary functions of this is illumination; independent auxiliaries exclusively for use with lighting equipment; UV and IR radiation appliances; neon advertising signs; street/flood lighting intended for outdoor use; transport lighting (installed in buses and trains)

WARRANTY

Systems, options and accessories thereof, manufactured and shipped under the AFJ Instruments brand name, are warranted to be free from manufacturing defects for a period of twelve (12) months from the date of shipment.

AFJ Instruments certifies that all products are tested and inspected to comply with the published specifications originating from the company. Calibration procedure includes Calculation of uncertainty using ISO model and traceability.

- Warranty is provided “Ex-Works”: therefore, AFJ Instruments will be responsible of the amendment of failures arising from ascertained manufacturing defects only.
- Warranty will not be applicable in case of mishandling, unauthorized opening of the cabinets, improper use, and unauthorized repairs. In such cases, the warranty will be terminated.
- A repair under warranty will not extend the original term of validity of the warranty itself.
- All products or parts thereof, to be subject to a warranty operation, shall be shipped to the appropriate AFJ Instruments Warranty Centre, at Customer’s charge.
- If a delivery back to the supplier is necessary we recommend keeping the original transport case. In such case, refer to the following Return Procedure.

Return Procedure

To return the VVL 1530 antenna to AFJ Instruments, use the following procedure:

- Briefly describe the problem in writing (Service Requested form). Include the serial number of the item being returned;
- Give details regarding the observed symptom(s), and whether the problem is constant or intermittent in nature. If you have talked previously to AFJ representative about the problem, provide such information also;
- Package the unit parts carefully, using the original boxes and packing materials, if possible. If not, use the most protective envelope at disposal (Damages due to transport are not covered from any guarantee);
- Before return the system back to AFJ, wait for RMA number (Returned Material Authorization).

DISCLAIMER OF LIABILITY

In no event shall AFJ Instruments be held liable for incidental or consequential damages of any kind whatsoever caused, or alleged to be caused directly or indirectly by the usage and operation of products herein, to customers or any third party, including, but not limited to, loss of use, loss of profit or any commercial loss.

Products described herein, do not imply any stated or alleged fitness for use, or any feasibility for business purpose, or expectation of profit. AFJ Instruments sole and only commitment is the compliance with the published product specifications.

All information in this manual is given in good faith. However, AFJ Instruments shall not be liable for any loss or damage whatsoever arising from the use of this manual, or any errors or omissions herein.

VVL 1530 – VAN VEEN LOOP ANTENNA
OPERATING MANUAL

TABLE OF CONTENTS

| | | | |
|------------|--|-------|----|
| SECTION A: | GENERAL INFORMATION | PAGE: | 5 |
| | 1.1. EU standard 55015 (CISPR 15) | | 6 |
| SECTION B: | PACKING LIST | PAGE: | 7 |
| SECTION C: | ASSEMBLY | PAGE: | 8 |
| SECTION D: | CALIBRATION LOOP | PAGE: | 15 |
| SECTION E: | CALIBRATION DATA | PAGE: | 19 |
| SECTION F: | OPERATION | PAGE: | 20 |
| SECTION G: | VVL 1530 TECHNICAL SPECIFICATIONS | PAGE: | 22 |
| SECTION H: | ANALYSIS OF CHANGES TO THE STANDARDS FOR VVL 1530 VEEN LOOP ANTENNA | PAGE: | 22 |

SECTION A: GENERAL INFORMATION

The AFJ VVL 1530 Van Veen Loop antenna has been developed to meet the requirements of EN 55015, Section 9.1.1, which refers to CISPR 16-1-4, Section 4.6.1.

This specifies the limits for magnetic field induced current for luminaries with lamp operating frequencies in excess of 100Hz.

Construction of the VVL 1530 is as detailed in Annex C of CISPR 16-1-4.

VVL 1530 antenna is fully compliant with the standard and details of the calibration factors are included in this manual.

Test set-up and measurement should be conducted as required by EN 55015, Section 4.4.



Fig.1: AFJ VVL 1530 Van Veen Loop antenna with AFJ CK 1530 calibration kit inside

The VVL 1530 is a complete 3-axis antenna with a switching unit to select each loop in turn. The loops are 2 metre in diameter with the lowest point 0,5 metre above ground and are fitted with specially designed current probes in fully screened housings.

The main framework is manufactured in wood with 25 mm diameter plastic tubing for the loops. When erected, a 2-metre Van Veen Loop antenna is a surprisingly large item: so, for ease of transportation and storage, the VVL 1530 is designed to be collapse down to sub unit of convenient size.

When used with the AFJ software supplied with the R3000 EMI receivers, the software displays the EN 55015 limits corrected for 2-meter loops.

A.1 EU standard 55015 (CISPR 15)

Limits and methods of measurement of radio disturbance characteristics of electrical lighting and similar equipment.

SCOPE:

This standard applies to the conducted and radiated emission of electromagnetic frequency disturbances from :

- all lighting equipment with a primary function of generating and/or distributing light intended for illumination purposes, and intended either for connection to the low voltage electricity supply or for battery operation;
- the lighting part of multi-function equipment where one of the primary functions of this is illumination;
- independent auxiliaries exclusively for use with lighting equipment;
- UV and IR radiation appliances;
- neon advertising signs;
- street/flood lighting intended for outdoor use only;
- transport lighting (installed in buses, trains, etc.).

Excluded from the scope of this standard are:

- apparatus for which the electromagnetic compatibility requirements in the radio frequency range are explicitly formulated in other IEC or CISPR standards.
Note - Examples are:
 - built-in lighting devices in other equipment, for example scale illumination or neon indicators;
 - photocopiers;
 - slide projectors.

EMISSION MEASUREMENTS

1. Radiated:

Requires the use of a 'Large Loop Antenna' (Van Veen Loop) antenna to measure the level of RF energy radiated from the product into 'space'. Frequency range 9KHz to 30MHz.

2. Conducted:

The RF conducted back down the mains lead is measured preferably with a LISN (Line Impedance Stabilisation Network), or alternatively with a voltage probe if a LISN is not suitable. Frequency range 9KHz to 30MHz.

SECTION B: PACKING LIST

On receipt of the AFJ VVL 1530, check the contents of the packages against the picture below.



Identify each component and check for shortages.
See also list overleaf.

| Qty | Item |
|-------|---|
| | <u>VVL 1530</u> |
| N. 3 | Large loops with current probes |
| N. 1 | Wooden structure: |
| | N. 4 - Corner posts |
| | N. 4 - Base extensions |
| | N. 1 - Central pillar |
| N. 20 | Cable ties |
| N. 1 | Manual switch unit |
| N. 3 | N - BNC cable fitted with ferrite absorbers |
| N. 1 | VVL 1530 Calibration certificate |
| | <u>Optional accessories</u> |
| N. 1 | Calibration kit (CK 1530): |
| | N. 1 - Calibration loop |
| | N. 1 - Support for calibration loop |
| | N. 2 - Wood stools (ES 1530) |
| N. 2 | Wood stools (ES 1530) |

SECTION C: ASSEMBLY

Herein below the main steps to assembly the AFJ VVL 1530.

1. Establish an appropriate area to erect the VVL 1530. This needs to be a clear area at least 4m square with a flat floor and a ceiling height of at least 3m.
2. In the centre of this area, set the central pillar as the sequence shown in Fig. 2.




Fig. 2: Central pillar setting

3. Fit the base extensions as shown in Fig. 3.



Fig. 3: Base assembly with set centre and base extensions

4. Slot the corner posts into the square hole at the end of each base as shown in Fig. 4.



Fig. 4: Corner posts setting

5. The 3 loops are delivered with current probes connected at one side. The connectors on each end of the loop are mated with the sockets for each current probe connection. Any loop and its current probe are indicated with X, Y and Z labels and stickers. See Fig. 5.




Fig. 5: Current probe connection

The first loop to mount is the horizontal loop. To mount the loops, at least two people are required. Mount the loop in the recesses at the top of each corner post with the current probe close to (within 5 cm) of a corner post. See Fig. 6. Slight 'drooping' of the loop between the posts has no effect on the performance of the antenna.



Fig. 6: Horizontal loop installation

6. The second loop is fitted inside the first (horizontal) loop, orientated so that it fits in the lower 'slot' in the central pillar and is held between the 'ears' on the corner posts as shown in Fig. 7. Arrange the loop so that the current probe is within 20 cm of the central pillar. For the moment, the loop will sag and generally not hold its shape. This will be resolved later.



Fig. 7: Second loop installation

7. The final loop is fitted INSIDE the other two as shown in Fig. 8. This fits in the upper slot in the central pillar, between the corner post 'ears' and under the other vertical loop at the top. Again arrange the loop so the current probe is close to the central pillar.



Fig. 8: Final loop installation

8. The loops can now be adjusted for best shape and position. The vertical loops shall be inserted into the guides on the top of the central pillar, which shall be closed fixing the cover according to the sequence with steps a, b, c and d shown in Fig. 9.




Fig. 9: Vertical loops and central pillar connection

The top of the vertical loops can be adjusted for best shape and position according to the sequence with steps a, b, c, d, e and f shown in Fig. 10.




Fig. 10: Vertical loops top connection

Note that the exact shape is not critical. Deviation from perfect circles is inevitable but this has no significant effect on antenna performance.

9. Connect the current probes to the switch unit as shown in Fig. 11. The 3 current probe cables are identified by having thick RF absorber filters along their length. Fit the cables so that these filters are nearest to the switch unit, which is intended for mounting on the antenna itself, according to the picture below. The N connector output from the switch unit is connected directly to the analyser or receiver through cable at customer care.




Fig. 11: Connections to switch unit

10. Within the loop a wooden stand or table can be used for EUT settings. AFJ ES 1530 is the optional available accessory for EUT supporting according to customer needs. Designed with two separated parts, it allows end user to set two different heights for EUT settings during measurements. See steps a and b in Fig. 12.



a



b

Fig. 12: AFJ ES 1530 EUT support settings

SECTION D: CALIBRATION LOOP

The AFJ CK 1530 calibration kit includes:

- calibration loop manufactured to comply with CISPR 16-1-4;
- support for the calibration loop:
- AFJ ES 1530.

CISPR 16-1-4 asks for setting calibration loop in horizontal and vertical position.

To set calibration loop in horizontal position, ES 1530 shall be set within the loops as shown in Fig. 12 with its five holes aligned as shown in Fig. 13.



Fig. 13: ES 1530 alignment for calibration loop in horizontal position

Set the support for the calibration loop on ES 1530 as shown in Fig. 14.



Fig. 14: Support setting for calibration loop in horizontal position

Install the calibration loop on its support as shown in Fig. 15.




Fig. 15: CS 1530 installation for calibration loop in horizontal position

To set calibration loop in vertical position, ES 1530 shall be set within the loops as shown in Fig. 16. with its five holes aligned as shown in Fig. 17.



Fig. 16: ES 1530 set within loops for calibration loop in vertical position



Fig. 17: ES 1530 alignment for calibration loop in vertical position

Set the support for the calibration loop on ES 1530 as shown in Fig. 18.




Fig. 18: Support setting for calibration loop in vertical position

Install the calibration loop on its support as shown in Fig. 19.



Fig. 19: CS 1530 installation for calibration loop vertical position

Full details of the use of the calibration loop are provided in this standard.

SECTION E: CALIBRATION DATA

The calibration data for each loop is virtually identical. The following details therefore apply to all three axes. For reference, the 'ideal' curve is shown in Fig. 20 (Ref. CISPR 16-1-4, Annex C).




Fig. 20: VVL 1530 'ideal' curve

The validation factor is measured at the 8 positions of the calibration loop as stated in the CISPR-16-1-4, Annex C, according to Fig. 21.




Fig. 21: Van Veen Loop antenna calibration setup

SECTION F: OPERATION

The method of measurement is given in EN 55015, section 4.4. A copy of this should be consulted if performing compliance tests.

The EUT should be mounted on a wooden frame or table in the centre of the antenna. The position is not critical.

To avoid unwanted capacitive coupling between the EUT and the large antenna system, the distance between the EUT and components of the Van Veen Loop antenna should be at least 0,10 times the loop diameter. Particular attention must be paid to the leads of an EUT. Cables should be routed together and leave the loop antenna volume in the same octant of the cell, no closer than 0,4m to any of the large antenna system, as shown in Fig. 22 (Ref. CISPR 16-1-4, Annex C).




Fig. 22: Example showing the routing of several cables from an EUT to ensure that there is no capacitive coupling from the leads to the loop


Each axis (loop) should be measured in turn. Each should meet the requirements of the standard. The loops are individually selected by the switch shown in Fig. 23.



Fig. 23: Switch unit

EXAMPLE: Measurement with the AFJ R3010 Receiver

1. Select the EN55015 limit (EN15 QP loop 2m);



2. Select the display unit of dBµA;
3. Set appropriate frequency parameters (in the section SINGLE TEST SETTINGS ► FREQUENCY TABLE);
4. Connect the switch unit to the appropriate EMI receiver 50Ω input;
5. With the EUT switched off, check the background signal level. If the background is too high, it is advisable to either find a 'quieter' location or screen the room;
6. Switch the EUT on. Check the levels of signal over the background levels using the techniques used for conventional radiated testing as described in the user guide. The levels displayed are fully compensated for the VVL 1530 characteristics and can be compared directly with the limit lines;
7. If the background and the product is 'quiet', and especially at frequencies above 20MHz, the pre-amplifier should be used to increase the sensitivity of the system. Set the Pre-amp buttons on the screen to **yes**. Care should be taken when using the pre-amplifier as the antenna then becomes extremely sensitive.

SECTION G: TECHNICAL SPECIFICATION

| | |
|--------------------|--|
| Design: | Fully compliance with CISPR 15 and CISPR 16-1-4 standards |
| Frequency Range: | 9kHz÷30MHz |
| Loops: | Triple independent 2m diameter loops, switchable among X, Y, Z |
| Selector: | Loop selection by manual switch unit |
| Output: | 50 ohm, N connector |
| Power requirement: | None |
| Dimensions | 2,6 x 2,1 x 2,1 m (height / width X / width Y) |

SECTION H: ANALYSIS OF CHANGES TO THE STANDARDS FOR VVL 1530 VAN LOOP ANTENNA

These changes are due to the amendments to CISPR 15 and CISPR 16-1-4.

The latest versions are now CISPR 15:2006 + A2:2009 and CISPR 16-1-4:2007 + A1:2008.

The key changes related to VVL 1530 are:

1. Sections related to the construction and specifications of VVL 1530 are moved from CISPR 15 to CISPR 16-1-4. Note that in the new CISPR 15, the requirements for the VVL 1530 are referred to Section 4.7.1 in the new CISPR 16-1-4, which does not exist!
It seems that the reference should be to Section 4.6.1. The same error is repeated in CISPR 16-1-4 which again refers in Annex C to the non-existent section 4.7.1.
2. The definition of the calibration data has been re-defined.

Note 1

The details of the VVL 1530 were given in Annex B of CISPR 15. These are now transferred to Annex C of CISPR 16-1-4. Most of the content has remained the same, but Table 1 summarises the changes.

| Previous CISPR15 | New CISPR16 | Notes | Significant changes |
|--------------------|-------------|--|---|
| Annex B Annex C | Annex C | Description, construction and validation of LAS | Both annexes combined into one. |
| Clause B1 | Clause C1 | Introduction | Loop antenna named LAS (Loop Antenna System) |
| Clause B2 | Clause C2 | Construction of LAS | Additional requirements for cables and connectors. |
| | Clause C3 | Construction of loop | Information previously included with diagrams now included in text. Note low R for inner conductor is required. |
| Clause B3 | ----- | Positioning of the LAS | Requirement for minimum distance to nearby objects,..... not included in new CISPR16 |
| Clause B4 | Clause C4 | Validation | New definition for validation factor. (see below). |
| Figure B1 | Figure C1 | General view | None |
| Figure B2 | Figure C2 | Position of slits | None |
| | Figure C3 | Construction of slits | None |
| | Figure C5 | Metal box for current probe | None |
| Figure B3 | Figure C4 | Example slit construction | None |
| Figure B4 | Figure C8 | Validation factor | Converted from dBuA to dB(Ω). See below. |
| | Figure C7 | Positions of calibration loop | None |
| | Figure C9 | Construction of calibration loop | None |
| Figure C1 | Figure C11 | Sensitivity vs diameter | None |
| Figure C2 | Figure C10 | Conversion factors between loop current and magnetic field strength at a distance. | Factors for magnetic field with electric field added. Factors for distance 30m removed. |

Note 2

CISPR 15 gave the verification data as a plot of loop current in dBuA vs frequency for the standard test signal (1V, open circuit voltage with a source impedance of 50ohm). This seems to be a straightforward method, especially as the limits are quoted in dBuA, so it's a direct correlation between the calibration loop and the limits.

CISPR 16-1-4 is essentially the same information, but presented differently. It specifies the relationship between the source voltage (1V, as specified above) and the output current in the loop as measured by the current probe. Note that the current probe has a transfer characteristic of 1V/A. The relationship between volts and current is ohms, hence the use of dB(ohms) as the 'validation factor'.

The result is therefore a conversion factor scaled in dB(Ω) to convert current to voltage, CISPR 16-1-4 defines the validation factor $\text{dB}(\Omega) = 20 \cdot \log(V_s/I_i)$ where V_s is the source voltage and I_i is the loop current.

$$V_s = 1V = 1,000,000Uv$$

Under 'old' CISPR15, for $I_i @ 100\text{KHz} = 46\text{dBuA} = 200\mu\text{A}$

So the new CISPR 16-1-4 value is $20 \cdot \log(1000000/200) = 74 \text{ dB}(\Omega)$

and

Old CISPR 15 for $I_i @ 30\text{MHz} = 29\text{dBuA} = 29\mu\text{A}$

So the new CISPR 16-1-4 value is $20 \cdot \log(1000000/29) = 91 \text{ dB}(\Omega)$

These calculations confirm the relationship between the CISPR 15 plot and the CISPR 16-1-4 validation factor.

The plots in the standards assume a current probe with a 1V/A transfer function. Such probes are 'active' but provide a flat frequency response. The VVL 1530 uses passive probes which have a non-flat frequency response. This is not important if the probe is 'inside' the calibration loop and has a linear transfer function with amplitude.